

Portero IP/SIP Android con reconocimiento facial

VTX-500

Ideal para uso en edificios, hoteles y oficinas, fácil de instalar y configurar

Descripción

El poderoso Intercomunicador con vídeo IP/SIP VTX-500, con sistema operativo Android, trae consigo la funcionalidad de control de acceso, permitiendo accionamientos mediante reconocimiento facial mientras que tiene sus manos ocupadas.

Controle quien llega a su vivienda, confirmando de manera verbal y visual la identidad de quien llama, como si fuera en persona, dando absoluta seguridad y una mayor tranquilidad.



Comunicación bidireccional abierta de audio y vídeo (IP/SIP)



Accionamientos remotos de los interruptores



Monitoreo en tiempo real, angulo de visión 120°



ANDROID SIP POE RFID



Especificaciones

Generales

- Pantalla IPS LCD táctil de 7" capacitiva
- Cámara de 3 Mpx con IR
- Calidad de audio y vídeo premium
- Cámara operativa permanentemente (Monitoreo)
- Accionamiento remotos de interruptores
- Múltiples métodos de acceso
- Android 5.1 / SIP / ONVIF / Wiegand / PoE / IP65 / IK06

Características SIP

- SIP v1 (RFC2543), SIP v2 (RFC3261)
- Linea: 2 Cuentas SIP

Características de entrada

- Lector de tarjetas RFID: 13.56MHz y 125kHz
- Teclado digital: Código de acceso
- Reconocimiento facial: 32 puntos de reconocimiento
- Otros métodos biométricos: Salida Wiegand

Características de audio

- Micrófono incorporado con clasificación IP67
- Altavoz 2W con clasificación IP66
- Códec: G.711a, G.711µ, G.722, G.729
- Calidad de voz: 7kHz
- Cancelación acústica de eco (CAE) en modo manos libres (tiempo de cola de 96ms)
- Detección de actividad de voz
- Generador de ruido Confort
- Max. Ajuste del tiempo de llamada

Características de vídeo

- Angulo de visión: 72°
- Resolución: hasta 1080p
- Velocidad de transferencia de imagen: 1080p @ 30fps máx.
- Modo auto nocturno con iluminación LED
- Iluminación: 0.1 LUX min.
- Balance de blancos automático
- Sensor de luz interno: lluminación de imagen durante horas oscuras
- Códec: H.263 y H.264
- Soporta RTSP y ONVIF

Características de red

- 1 Puerto RJ45 Ethernet 10/100 Mbps
- Configuración IP: estática / DHCP
- Control de acceso de red: 802.1x
- NTP para ajustes de horario por red

Características de gestión y operación

- Auto-provisioning vía FTP/TFTP/HTTP/HTTPS/PnP
- Gestión a través de portal web o su pantalla táctil







- Packet-dump basado en web
- Backup de configuración para exportar e importar
- Actualización de firmware

Características físicas

- Pantalla táctil capacitiva 7" IPS LCD
- RAM / ROM: 2GB / 16GB
- Cámara 3 Mega píxeles, iluminación automática Sensor IR
- Consumo de energía: entrada 12V DC, <12W</p>
- G-sensor para alarma de sabotaje (Tamper)
- Relé de entrada / salida: 3
- Relés controlados individualmente por tonos DTMF
- Puerto Wiegand / RS485
- Material del cuerpo: Panel de Aluminio
- Instalación: Montaje empotrado o superficial en pared
- Dimensiones: 324x130x27mm.
- Certificaciones industriales: IP65, IK06





Para más información sobre Cygnus Electronics visite: <u>www.cygnus.la</u> – Cygnus Electronics y su respectivo logo son marcas registradas de Cygnus Electronics y /o sus afiliados en la Argentina y otros paises. Cualquier marca de terceros mencionada es propiedad de sus respectivos dueños.



Guía de inicio rápido



Ethernet (POE): Conector Ethernet (POE) puede proporcionar conexión de red y de alimentación. **12V / GND:** Terminal de alimentación externa si POE no está disponible.

WG_D0 / 1: Terminal Wiegand para control de acceso Wiegand.

RS485A / B: Terminal RS485, automatización. **DOOR A / B / C:** terminal de entrada de señal de activación (por ejemplo, presione el botón interior para abrir el relé).

Relé A/B/C: Terminal de control de relé. (NO / COM / NC)



Escenario de aplicación



Configuración

 <u>Desde la pantalla del dispositivo</u>: presione **9999** en la interfaz de marcación, luego ingrese **3888** para ingresar a la interfaz del sistema. Haga clic en Información para comprobar la dirección IP. VTX-500 utiliza **DHCP** de forma predeterminada. En la interfaz de web, vaya a **Red** -> Básico.

 <u>Registro de cuenta</u>: en la interfaz de usuario web, vaya a la ruta: **Cuenta** -> Página básica para registrar la cuenta y completar la información de la cuenta. (Por favor, consulte el manual del usuario para más información)

3. <u>Configuración del código DTMF</u>: en la interfaz de usuario web, vaya a la ruta: **Teléfono** -> Configuración de la puerta -> DTMF y elija el número del código DTMF en el área correspondiente.



Alta de contacto

Ingresando al menú local (Configuración 1), vaya a Contacto -> Agregar un contacto.

ъ

08:01

Importante: El número de teléfono a completar, puede ser una extensión SIP o la dirección IP de un dispositivo dentro del sistema.



Realizar una llamada

Desde la pantalla principal presione ->

Marcar, para discar una extensión SIP (101) o una dirección IP (192*168*16*220)



Alta rápida de rostro

Habilitar función desde interfaz web. En Intercomunicador -> Face.

1. Luego desde la pantalla del dispositivo, ingresar al menú local (Configuración 1), vaya a Rostro -> Agree.

2. Acerque su cara al marco, y mantenga mientras el proceso de registro de lleva acabo.

3. Identifique con nombre el rostro cargado.



Para más información vea su manual y hoja de datos en:

www.cygnus.la/manuales/cy-vtx-500.pdf

www.cygnus.la/hojasdedatos/cy-vtx-500.pdf

Contactos, para elegir un número guardado en la agenda local del dispositivo.





User Manual VTX-500

1. Product Overview
1.1. Instruction1
1.2. Connector Introduction2
1.3. Warning
2. Daily use
2.1. Make a Call
2.1.1. Call From Digital Keypad4
2.1.2. Call From Phonebook
2.2. Receive a Call
2.3. Unlock
2.3.1. Unlock by Pin Codes
2.3.2. Unlock by Face
2.3.3. Unlock by RFID cards
2.3.4. Unlock by DTMF codes
3. Basic Features
3.1. Access the system setting7



3.4.4.3. Door Setting General	15
3.4.4.4. Home View Visible Control	
3.4.5. Volume	
3.4.6. DND	
3.5. Phonebook	19
3.6. Intercom call	
3.6.1. IP Direct Call	
3.6.2. SIP Call	
3.6.2.1. Account	
3.6.2.2. SIP Account	24
3.6.2.3. SIP Server	
3.6.2.4. Outbound Proxy Server	
3.6.2.5. Transport Type	27
3.6.3. Dial Plan	27
3.6.4. Quick Dial	
3.6.5. Auto Answer	
3.6.6. No Answer Call	

	3.6.7. Web Call	30
3.7	. Security	31
	3.7.1. Mjpeg Service	31
	3.7.2. Live Stream	31
	3.7.3. RTSP	32
	3.7.4. ONVIF	33
3.8	. Access control	33
	3.8.1. Relay	33
	3.8.2. Unlock via RFID Cards	35
	3.8.2.1. RFID Cards in devices	35
	3.8.2.2. RFID Cards in website	36
	3.8.3. Unlock via Pin Codes	37
	3.8.3.1. Private Pin Codes in Device	37
	3.8.3.2. Private Pin Codes in website	38
	3.8.3.3. Public Pin Codes in device	39
	3.8.3.4. Public Pin Codes in websites	39
	3.8.4. Unlock via Face	40

	3.8.4.1. Face in Device	40
	3.8.4.2. Face in Website	40
	3.8.5. Unlock via HTTP Command	
	3.8.6. Unlock via Exit Button	43
3.9	9. Reboot	44
3.1	10. Reset	45
4. Adv	vanced Features	
4.1	1. Phone Configuration	
	4.1.1. IR LED	46
	4.1.2. LED of Display	47
	4.1.3. RFID Card Code Display Related	47
4.2	2. Intercom	
	4.2.1. Call Time Related	
	4.2.2. Return Code When Refused	
	4.2.3. SIP Call Related	
	4.2.4. Call Waiting	50
	4.2.5. Intercom	51

4.2.6. Codec	
4.2.7. DTMF	
4.2.8. Session Timer	
4.2.9. NAT	54
4.2.10. User Agent	55
4.3. Access control	
4.3.1. Webrelay	
4.3.2. Wiegand	
4.4. Security	
4.4.1. Antialarm of Door Phone	
4.4.1.1. Antialarm in device	
4.4.1.2. Antialarm in website	59
4.4.2. Motion	60
4.4.2.1. Motion in device	
4.4.2.2. Motion in website	61
4.4.3. Action	62
4.4.3.1. Email Notification	



4.4.3.2. FTP Notification	63
4.4.3.3. Input Interface Triggered Action	63
4.5. Upgrade	64
4.5.1. Web Update	64
4.5.2. Autop Upgrade	64
4.5.3. Backup Config File	66
4.6. Log	67
4.6.1. Call Log	67
4.6.2. Door Log	67
4.6.3. System Log	68
4.6.4. PCAP	68

2. Daily use

CYGNUS 🐎

2.1. Make a Call

There are two ways to make a call from the door phone to monitor units, which can be an indoor monitor or an intercom app.

2.1.1. Call From Digital Keypad

The default interface of the door phone is the dial interface. Enter the number to call on the digital keypad, and press the dial icon.

2.1.2. Call From Phonebook

In the phonebook interface, to find a specific occupant, scroll up or down the pre-imported contact list, which is either a room number, an occupant's name, or the combination of both. It also supports searching the list by alphabet and then clicking the dial key next to the found contact.



Figure 2.1.1 Dial interface



2.2. Receive a Call

When a monitor unit calls the door phone, it will auto answer the incoming call by default. There is no need to press any answer key.

2.3. Unlock

CYGNUS

2.3.1. Unlock by Pin Codes

Unlock the door by using predefined public pin or private pin. Press "Pin Code", "Unlock" icon to unlock, then you will hear "The door is now opened" and the screen will show "Open Lock Success". If users input the wrong pin code, the screen will show "Password Error".

2.3.2. Unlock by Face

Unlock the door by using predefined face. Enter the unlock interface, close your face to the camera. You will hear "the door is



Figure 2.3.1 Unlock by pin code

Figure 2.3.2 Unlock by face

opened" and screen will show "Open Lock Success".

2.3.3. Unlock by RFID cards

CYGNUS

Place the predefined users card in RFID cards reader to unlock. Under normal conditions, the phone will announce "The door is now opened" and the screen will show "Open Lock Success". If the card has not been registered, the phone will show "Open Lock Failed".

2.3.4. Unlock by DTMF codes

During the calling, the president can press the predefined DTMF codes to remote unlock the door.



3. Basic Features

CYGNUS

3.1. Access the system setting

In the Dial interface, press "9999", "Dial key", "3888", "OK" to enter the system setting. System setting is easy to configure most basic phone functions.

3.2. Access the website setting

3.2.1. Obtain IP Address

VTX series use DHCP IP by default. Enter the phone interface and go to **Info** to check the IP address.



Figure 3.1-1 Access the system setting

Figure 3.1-2 Access the system setting



3.2.2. Access the Device Website

CYGNUS

Open a web browser, and access the corresponding IP address. Enter the default user name and password to login. The default administrator's user name and password are shown below: User Name: **admin** Password: **admin**

Note: The recommended browser is Google Chrome.

3.3. Password Modification

3.3.1. Modify the Phone System Password

Users can configure project key with this function. The public key is a password used by all occupants in a building. Project key is used by administrators for some basic settings. There are two ways to change the system password, which can be done on the phone system and on the intercom website.

Login		
	User Name	admin
	Password	•••••
		Remember Username/Password
		Login



Pa	Password				
Project Passwd	Public Key Passwd				
Old Passwd					
New Passwd					
Passwd Confirm					
	Davie				

Figure 3.3.1-1 Modify the system password



In the phone interface, go to the **Password - Project Passwd** to change the project key passwd.

Project Passwd: Enter the 4 digits old project key, the default project key is "9999". Then enter the 4 digits new passwd, after entering the new passwd confirm, click **save** icon .

In the website, go to the path Intercom - Basic - Password to configure.

3.3.2. Modify the Web Password

Login to the website and go to the path **Security** - **Basic**, to modify password for "admin" or "user" account.

ProjectKey	9999	
User Setting Key	3888	

Figure 3.3.1-2 Modify the system password

Web Password Modify					
User Name	admin 🔻				
Current Password					
New Password					
Confirm Password					

Figure 3.3.2 Modify the web password

3.4.2. Time

CYGNUS

In the phone interface, go to **Time** to configure. Choose automatic date & time setting for automatic access of time, date and time zone. Or set the time, date and time zone manually.

3.4.3. Network

In the phone interface, go to **Address** or login to the website and go to the path **Network - Basic**, dynamically or statically to obtain address.

3.4.3.1. DHCP Mode

VTX series uses DHCP mode by default which will get IP address, subnet mask, default gateway and DNS server address from DHCP server automatically.

		06:38				6:00 AM
					e	
	2018/9/12 0	06:38:23	Wednesday		DHCP	V
Automatic	date& time					
Date						
	2018	9	12			
	~		w.			
Time	-	e d	a .			
	6	1	38			
	-		Ψ.			
TimeZone		Azores	GMT+0:00	þ		
	-	Save				Save
	-					
I	Figure 3	8.4.2	Time		Figure	e 3.4.3.1-1 DHCP mode

	LAN Port
DHCP	
Static IP	
IP Address	192.168.16.100
Subnet Mask	255.255.255.0
Default Gateway	192.168.16.1
LAN DNS1	192.168.16.1
LAN DNS2	192.168.16.1

Figure 3.4.3.1-2 DHCP mode

3.4.3.2. Static Mode

If select static IP, users should manually setup IP address, subnet mask, default gateway and DNS server address. The figure right shows static IP setting.







	LAN Port
O DHCP	
Static IP	
IP Address	192.168.1.100
Subnet Mask	255.255.255.0
Default Gateway	192.168.1.1
LAN DNS1	192.168.1.1
LAN DNS2	

Figure 3.4.3.2-2 Static mode

3.4.4. Display

3.4.4.1. Await

In the phone interface, go to **Await** or login to the website and go to the path **Intercom - Advanced - StandBy**, to set the standby mode, standby time and unlock mode.

Standby Mode: There are three options for the standby mode. 'NO' mode is for the door phone's default dial interface to remain permanently on; "Blank" mode screen is a black screen during standby; and "Picture" mode is a chosen screensaver of your like, which can be imported in bulk by the administrator.

Standby Time: Users can set the standby time from 30 Sec to 180 Sec.

Unlocked Mode: To choose how to wake up the door phone from the standby mode.



St	andBy
StandBy Mode	[Image 🔹
StandBy Time	60 🔻
Unlocked Mode	Auto 🔻

Figure 3.4.4.1-2 StandBy

3.4.4.2. Upload ScreenSaver

CYGNUS

In the website and go to the path **Phone - Import/Export - Upload screensaver** to configure. To upload screen saver and set the corresponding interval time and the priority. It will be displayed on screen when VTX series stand by type as picture. Up to 5 different screen savers can be supported. These pictures will scroll to display. The format must be .jpg. If the interval time is 0, it won't be displayed.

If users need to upload many pictures, please choose the ID order of the picture. For example, users need to upload the first picture as ID 1 which will be first screensaver to display, users will choose Image 1. Then users will upload the second one, users need to choose Image 2 and so on.

Screensaver1: To choose the favorite image, and upload it (the most suitable image size is 1280*800).

After uploading, the pictures will be in the list. Then users need to





creensaver1	Choose File	No file chosen	Upload
-------------	-------------	----------------	--------



manually setup the Interval time which means how long the image will display then change to next screensaver. Interval range from 0 to 120s. Click the **Submit** to save each one. Click **Delete** to

remove the picture.

3.4.4.3. Door Setting General

CYGNUS

In the website and go to the path Intercom - Basic - Door Setting General to configure.

Display Type: Setup the home page's default display interface. There are four types can be choice "Dial", "Contact", "Only-Contact", "Password".

Number of Show Contacts: Users can setup 0 to 8 top contacts under only -contact mode. The top contacts are some important or commonly used numbers.

DialPad Input Number Limit: To limit the input numbers to prevent unnecessary security problems.

	Upload S	ScreenSav	er <mark>(.jpg</mark>)	
ID	File Status	Interval	Submit	Delete
1	File Exists	3	Submit	Delete
2	File Exists	3	Submit	Delete
3	NULL	0	Submit	Delete



Display Type	Password 🔹
	Dial
RTP TimeOut	Contact
	Only-Contact
Number of Show Contacts	Password

Figure 3.4.4.3-1 Display type

Number of Show Contacts	4	•
Figure 3.4.4.3-2 Nu	umber of show contac	ts
20.20	- Contraction	
DialPad Input Number Limit	Default	۲

3.4.4.4. Home View Visible Control

In the website and go to the path Intercom - Basic - How View Visible Control to configure.

Users can setup whether the home page-dial interface, contact interface, unlock interface is visible. For example, if users enable dialview, users will only see dialing interface, the other two will be hided.

3.4.5. Volume

CYGNUS

In the phone interface, go to **Volume**, to configure the call volume, AD volume and key volume.

Call Volume: When VTX series dials out a call, it will prompt the 'du' sound. To configure the call volume by yourself.

AD Volume: When the door is opened, the phone will announce the opendoor tone. To configure the AD volume by yourself.

Key Volume: When touch the screen, that will be a prompt

Home Vie	w Visible Control
DialView	VISIBLE
ContactView	VISIBLE
Password	VISIBLE

Figure 3.4.4.4 How view visible control



Figure 3.4.5-1 Phone volume

sound.To configure the key volume by yourself.

CYGNUS

Also users can modify the other voice settings in the website. **Call Volume:** Login to the website and go to the path **Phone - Call Feature - Others** to show the volume adjustment in talking interface.

Mic Volume: Login to the website and go to the path **Phone** - **Voice**, to configure Mic volume.

Login to the website and go to the path Intercom - Advanced -

Open Door Warning to configure.

Open Door Warning: Disable it, users will not hear the prompt voice when the door is opened.

Open Door Tone: Login to the website and go to the path **Phone** - **Import/Export - Open Door Tone** to upload the Opendoor tone by

Call Volume	Enabled 🔻	
Figure 3.4	.5-2 Call volume	
Mi	c Volume	
Mic Volume	60	(0~127)
Figure 3.	4.5-3 Mic volume	
Open I	Door Warning	
Open Door Succ	ON	•
Open Door Failed	ON	•
Figure 3.4.5-	4 Open door warning	
Open Do	or Tone (.wav)	

Figure 3.4.5-5 Upload the open the door tone

Import

Reset

Choose File No file chosen



Tone

yourself.

Open Door Tone: Users can also go to the path **Intercom - Door Setting General** to configure the switch whether users will hear the "the door is opened" announcement.

3.4.6. DND

DND allows IP phones to ignore any incoming calls. Users can login to the website and go to **Phone - Call Feature** to configure. **Return Code when DND:** Determine what response code should be sent back to server when there is an incoming call if DND on. **DND On Code:** The code used to turn on DND on server's side, if configured, IP phone will send a SIP message to server to turn on DND on server side if user press DND when DND is off. **DND Off Code:** The code used to turn off DND on server's side, if configured, IP phone will send a SIP message to server to turn on

Open Door Tone	Enable
----------------	--------



All Account
Disabled 🔻
486(Busy Here)

Figure 3.4.6 DND

3.5. Phonebook

In the phone interface, go to **Contact** to configure the phonebook. **Create a group:** Choose group, click **Add** to enter the new group name. Press of to save.

Edit a group: Choose the existed group to modify or delete.

Create a contact: Click **Add** to enter the contact's information. Choose a suitable Group and contact's name and Phone number,

press 🥏 to save.

Edit a contact: Choose a exist contact to edit or delete it.



Figure 3.5-1 Adding group





Controls Contro

Figure 3.5-3 Adding contact



In the website, go to the path **Phonebook - Local Book** to configure the phonebook.

Contact: To display or edit all local contacts.

Search: Enter the key word to search designated contacts from local phonebook.

Contact Setting: Choose a suitable contact picture, then import (optional);Enter the corresponding contact name and phone number; Click **Add** to save.

Note: The photo only supports .png format.

Group: To check all group in the list or choose one to delete.

Group Setting: Enter the new group name, click Submit to save;



Figure 3.5-6 Contact setting





Users can also login to the website and go to the path Phone -

Import/Export - **Import/Export** Config&Contacts to upload or download the contact information.

Contact: Click **Export** to export the existed contact. Choose the local file and click **Import** to import the new contact. The export format is .vcf, the import format is .vcf, .csv or .xml. The import maximum is 3000.

Login to the website and go to the path **Intercom - Basic - Door Setting General** to configure item touch and contact profile picture function.

Item Touch: This function is convenient for users to press anywhere in the contact line to call out, don't have to call out to touch the call button.

Contact Profile Picture: To setup whether it will show contact picture or not.

Contacts:	Choose File	No file chosen	Import	Export •
	-			

Item Touch	Enable	•
Contacts Profile Picture	Enable	•

Figure 3.5-9 Contact display

3.6. Intercom call

3.6.1. IP Direct Call

In the dial interface. Enter the number to call on the digital keypad, and tap the dial icon. Without SIP server, users can also use IP address to call each other. However, this way is only suitable in the LAN. Enter the IP address of the callee, and press the **dial** icon.

Login to the website and go to the path Phone - Call Feature -

Others to configure the call related features.

Direct IP: To call someone with dialing IP address directly.

Direct IP Port: To configure the direct IP port.



Figure 3.6.1-1 Dial interface

Direct IP	Enabled T	
Direct IP Port	5060	(1~65535)

Figure 3.6.1-2 Direct IP

3.6.2. SIP Call

SIP call uses SIP number to call each other which should be supported by SIP server. Users need to register an account and fill some SIP feature parameters before using SIP call.
Login to the website and go to the path Account - Basic to configure SIP account and SIP server for door phone first.

3.6.2.1. Account

VTX series supports 2 accounts. According to your needs, register one or two accounts and users can switch them by themselves. Enter the system setting interface, choose account. According to the configuration of PBX, enter the account parameters. Tick enable to active the account. If you register 2 accounts in the same time. VTX series will choose the account 1 as the default account.

3.6.2.2. SIP Account

In the phone interface, go to **Account** - **Account setting** - **Account 1&2** to configure the SIP account.

Enable Account: SIP account is only available if you enable this account.

Register Name: To enter extension number you want and the number is allocated by SIP server.

User Name: To enter user name of the extension.

Password: To enter password for the extension.

Display Name: To configure name sent to the other call party for displaying.

Note: After configurations, users can go to the website - Account

- Basic - SIP Account to check the register status.

)	07-48 Account setting			
Ao	count 1	Account 2		
Enable Account	ल			
Register Name	108			
User Name	108			
Password				
Display Name	108			

Figure 3.6.2.2-1 SIP account



Login to the website and go to the path Account - Basic - SIP

Account to configure the SIP account.

Status: To display register result.

Account: Select the SIP account you need to configure.

Account Active: SIP account is only available if users enable this account.

Display Label: To configure label displayed on the phone's LCD screen.

Display Name: To configure name sent to the other call party for displaying.

Register Name: To enter extension number users want and the

number is allocated by SIP server.

User Name: To enter user name of the extension.

Password: To enter password for the extension.

	SIP Account
Status	Registered
Account	Account 1
Account Active	Enabled 🔹
Display Label	108
Display Name	108
Register Name	108
User Name	108
Password	••••••

Figure 3.6.2.2-2 SIP account

3.6.2.3. SIP Server

CYGNUS

In the phone interface, go to Account - Account setting -Account 1&2 to configure the SIP server. Users can also go to the path Account - Basic - SIP Server 1&2 to configure. Server IP: To enter SIP server's IP address or URL. Server Port: To enter the SIP server port. Registration Period: The registration will expire after registration period, the IP phone will re-register automatically within registration period.

3.6.2.4. Outbound Proxy Server

Login to the website and go to the path **Account - Basic -Outbound Proxy Server** to display and configure outbound proxy server settings. An outbound proxy server is used to receive all initiating request messages and route them to the designated SIP server.

Out	bound Proxy Server	
Enable Outbound	Disabled 🔻	
Server IP	Port 50	60
Backup Server IP	Port 50	60

Figure 3.6.2.4 Outbound proxy server

Reg Server IP	192.168.10.27
Reg Server Port	5060
	Save
Figur	re 3.6.2.3-1.SIP server

	SIP Server 1	
Server IP	192.168.10.27	Port 5060
Registration Period	1800	(30~65535s)

Figure 3.6.2.3-2 SIP server

3.6.2.5. Transport Type

To display and configure transport type for SIP message **UDP:** UDP is an unreliable but very efficient transport layer protocol.

TCP: Reliable but less-efficient transport layer protocol.

TLS: Secured and Reliable transport layer protocol.

DNS-SRV: DNS record for specifying the location of services.

3.6.3. Dial Plan

Replace Rule

Replace rule is using some simple number or symbol to replace a complicated phone number or IP address. It is more suitable for some one who want to hide the real phone number or simplify the long number. This is more convenient for users.

In the phone system, go to **Replace Rule**, click **Add**, choose a suitable account and enter the value, press **OK** to confirm. It

			unspe	ne typ	•		
Туре				UDP	,	1	۲
	Figu	ire 3	.6.2.5	Transp	oort typ	e	
			4	8-42			
		Ad	d Dial Re	place			
AC PT		Aci	count	Auto Acc	ount		
-		Pre	efix	10			
		Rej	place	92.168.16	.134		
		Re	place2	92.168.16	i.137		
		Rej	place3	-	_		
		Rej	place4		-		
		Rej	place5		-		
			×	0			
		L.,	~	_			
	+	Pause	1	2 MIC	3 007	a	
		Welt	4 04	5 412	6 MIND	Next	
(Э	N	7 Pages	8 TUV	9 wsvz		
			*				

Trar

supports a prefix number replace 5 number at the same time, when the user press the prefix number, the 5 devices will ring at the same time.

For example:

Users can pre-configure 10 to replace 192.168.16.134 and 192.168.16.137 in the doorphone. Then, by pressing 10, the two devices can be dialed at the same time through the default account without having to remember the long phone number or dial separately.

Users can also login to the website and go to the path **Phone - Dial Plan** to configure this function. VTX allows users to modify replace rule in the website.

All replace rules will show in the list. Users can edit or delete the exited replace rules.

Account	Auto
Prefix	1
Replace 1	192.168.16.187
Replace 2	192.168.16.134
Replace 3	
Replace 4	
Replace 5	

Figure 3.6.3-2 Dial plan

Rule	es		Replace	Rule •				
Index Account Prefix		Replace 1	Replace 2	Replace 3	Replace 4	Replace 5		
1	Auto	1	192.168.16.187	192.168.16.134				
2								

Figure 3.6.3-3 Dial plan
3.6.4. Quick Dial

CYGNUS

Quick Dial is to call predefined important number quickly in main interface. This number is often set as emergency number. In the phone interface, go to **Quick Dial**, switch the type as quick dial, enter the quick dial name and number, click **Save** to confirm.

3.6.5. Auto Answer

Login to the website and go to the path **Account - Advanced - Call** - **Auto Answer** to enable the auto answer.

Login to the website and go to the path Phone - Call Feature -

Others to configure the auto answer related function.

Return Code When Refuse: Allow users to assign specific code as return code to SIP server when an incoming call is rejected.

Auto Answer Mode: To choose video or audio mode for auto answer.



 Auto Answer
 Enabled

 Figure 3.6.5 -1Auto answer

 Others

 Return Code When Refuse
 486(Busy Here)

 Auto Answer Delay
 0

 Auto Answer Mode
 Video

Figure 3.6.5 -2 Auto answer



Auto Answer Delay: To configure delay time before an incoming call is automatically answered.

3.6.6. No Answer Call

This feature is used to transfer the call to the target number in order if the calling is no answered with timeout. Login to the website and go to the path **Phone - Call Feature - No Answer Call** to configure.

To setup two no answer call number. They will be called by order.

3.6.7. Web Call

Login to the website and go to the path Phonebook - Local Book -

Dial to dial out from website.

Dial: To dial out a call or hangup an ongoing call from website.



Figure 4.2.4 No answer call



3.7. Security

CYGNUS

3.7.1. Mjpeg Service

Login to the website and go to the path Intercom - Advanced -

Mjpeg Server to configure.

Mjpeg Service Enable: Use to capture from the URL. It is convenient to check the capture remotely.

Image Quality: To choose the image quality of the capture.

Picture URL:

http:// device ip:8080/picture.cgi

http://device ip:8080/picture.jpg

http://device ip:8080/jpeg.cgi

3.7.2. Live Stream

Login to the website and go to the path **Intercom - Live Stream**, check the real-time video from VTX. In addition, users can also

Mjpeg	Service	
Mjpeg Service Enable	ON	•
Image Quality	1080P	•

Figure 3.7.1 Mjpeg service



Figure 3.7.2 Live view

check the real-time picture via URL:

http://IP_address:8080/picture.

3.7.3. RTSP

CYGNUS

RTSP Basic

VTX series support RTSP stream, enter the phone system, go to **RTSP** or login to the website and go to the path **Intercom - RTSP**, to enable or disable RTSP server. The URL for RTSP stream is: **rtsp://IP_address/live/ch00_0**

• H.264 Video Parameters

H.264 is a video stream compression standard. Different from H.263, it provides an approximately identical level of video stream quality but a half bit rate. This type of compression is sometimes called MPEG-4 part 10. To modify the resolution, framerate and bitrate of H.264.



	RTSP Bas	ic
RTSP Enable	0	
	Figure 3.7.3-2	2 RTSP
	H.264 Video Par	ameters
Video Resolution	1080P	
Video Resolution Video Framerate	1080P 25 fps	•

Figure 3.7.3-3 H.264 video parameters

3.7.4. ONVIF

VTX-500 supports ONVIF protocol, which means VTX series camera can be searched by other devices, like NVR, which supports ONVIF protocol as well. Go to the path **Intercom** - **ONVIF** on the web GUI, to configure ONVIF mode and its username/password.

Switching ONVIF mode to "undiscoverable" means that Users must

program ONVIF's URL manually.

The ONVIF's URL is:

http://IP_address:8090/onvif/device_service

3.8. Access Control

3.8.1. Relay

Login to the website and go to the path **Intercom - Relay** to configure.



Figure 3.7.4 ONVIF setting

Relay ID: VTX series supports three relays. Users can configure them respectively.

Trigger Delay: To configure the duration of the trigger relay. With the trigger condition, the relay will only be triggered if the value is reached.

Hold Delay: To configure the duration of opened relay. Over the value, the relay would be closed again.

DTMF Option: To select digit of DTMF code, VTX series supports maximum 4 digits DTMF code.

DTMF: To configure 1 digit DTMF code for remote unlock

Multiple DTMF: To configure multiple digits DTMF code for remote unlock.

Relay Status: While the relay is triggered, the statues will be switched. When COM connects to NC, the status is Low.

Note: Relay operate a switch and does not deliver power, so users should prepare power adapter for external devices which connects to relay.

		R	elay			
Relay ID	RelayA	•	RelayB	T	RelayC	v
Trigger Delay(sec)	0	•	0	•	0	•
Hold Delay(sec)	5	•	5	•	5	۲
DTMF Option	1 Digit DTMF	•				
DTMF	0	•	1	•	2	•
Multiple DTMF	010		012		013	
Relay Status	RelayA: Low		RelayB: Low	,	RelayC: Lo	N
	Figure	38	3 1 Relay			

3.8.2. Unlock via RFID Cards

3.8.2.1. RFID Cards in Devices

VTX series can be compatible with 13.56MHZ and 125KHZ RFID cards.

Add

CYGNUS

Press "**Add Card**", when you see "Please scan the RFCard to Add", put the card near the card sensor. Then enter the card name, valid day and time in the modify prompt. Click **OK** to save.

Modify

Press "**Del Card**", when you see "Please scan RFCard to Delete", put the exited card near the card sensor, click **Del** to delete in the modify prompt. Or users can just choose the existed card from the list, delect directly.



Figure 3.8.2-1 RFID key

Figure 3.8.2-2 RFID key

3.8.2.2. RFID Cards in Website

Go to the path **Intercom - Card setting**, to manage RFID cards access system.

Import/Export Card Data: Export the existed RFID cards information or import the new RFID cards information. It can only support .xml format. The maximum is 1000.

Note: Ask your administrator for the card data template if you need.

Obtain and Add Card:

- (1) Switch card status to "Card Issuing" and click "Apply";
- (2) Place card on the card reader area and click "Obtain";
- (3) Name card and choose which door you want to open and the valid day and time;
- (4) Click "Add" to add it into list.





CYGNUS

Door Card Management:

Valid card information will be shown in the list. Administrator could

delete one card's access permission or empty all the list.

Note: Remember to set card status back to normal after adding the cards.

3.8.3. Unlock via Pin Codes

3.8.3.1. **Private Pin Codes in Device**

In the phone interface, go to LockPasswd, enter the owner name, 8 digits private keys and Device (optional). Setup the valid day and time for the password.

For example:

Owner name is Eve, private key is 12345678, and I set up the valid

day from Mon to Sun, click 🤎

to save.

boor card Humagement					
Index	Name	Code	Relay	Device Name	
1	test	FF96A228	1	Cygnus	
2	test1	00645C0E	1		
3					
4					

Figure 3.8.2-6 Door card management



Figure 3.8.3.1-1Adding private key

Figure 3.8.3.1-2 Editing private key

3.8.3.2. Private Pin Codes in Website

Go to the path **Intercom - Privatekey** on the web GUI, to manage RFID cards access system.

Import/Export Private Key: Export the existed private key information or import the private key from local side. It can only support .xml format. The maximum private key is 1000.

Obtain and Add Code:

- (1)Enter the "PKey Name" and "PKey Code";
- (2)Select the valid day and time;
- (3)Choose which door users want to open;
- (4)Click "Add" to add it into list.

Private Key Management:

Valid private key information will be shown in the list. Administrator could delete private key information or empty all the list.

Choose File	No file chosen	Import	Export

	Private Key Setting
PKey DoorNum	RelayA 🗹 RelayB 📄 RelayC 📄
PKey Day	Mon 🗹 Tue 🗹 Wed 🗹 Thur 🖉
PRey Day	Fri 🗹 Sat 🖉 Sun 🗹 Check All 🗌
PKey Time	00 •:00 •:00 •
PKey Name	test
PKey Code	1111111
Device Name	Add

Figure 3.8.3.2-2 Private key setting

Index	Name	Code	Relay	Device Name	
1	Eve	12345678	123		
2	test	11111111	1		
3					
4					

Figure 3.8.3.2-3 Private key management

3.8.3.3. Public Pin Codes in device

CYGNUS

In the phone interface, go to **Password - Public Key Passwd**, enter the old public key, VTX series support 3 default public keys. Then enter the new passwd, after entering the new passwd Confirm, click **save** icon.

Note: Just need to enable public key passwd in public key passwd setting.

3.8.3.4. Public Pin Codes in websites

Go to the path **Intercom - Basic - Password**. Users can configure project key and public key with this function. Public key is the password used by all occupants in a building.

Public Enable: The default status is on.

PublicKey Bits Limit: Setup the key digits.

Public Key: VTX series support 3 default public keys, users can reset a new public key.





Pas	sword
PublicKey Enable	ON •
Pub <mark>lic</mark> Key Bits Limit	Default(8 Bits)
PublicKey_0	3333333
PublicKey_1	66666666
PublicKey_2	8888888

Figure 3.8.3.4 Password

3.8.4. Unlock via Face

3.8.4.1. Face in Device

In the phone interface, go to Face to record the Face ID.

Add:

CYGNUS[%]

Close your face to the camera, in the middle of the round box on the screen. If a face is recognized, the face ID will be automatically admitted. Click "Confirm" after the recognition is completed, then enter the face registration name and click "Register" to save the face ID.

Modify:

Click Face database, choose the existed database to delete.

3.8.4.2. Face in Website

Go to the path Intercom - Face on the web GUI to configure the face information.







Figure 3.8.4.1.1 Face recognition

Figure 3.8.4.2.2 Face recognition



Face Threshold: Smaller the value, lower the face accuracy.

Search: Enter key word to quick search. Check the exited face data from the list.

Face Data: Support to import or export the face data. The export format is .tgz, the import format is .zip.

Import/Export file: Because VTX series can not support the third party camera to enter the face picture now. Users need to directly take face data in the VTX series, then export the existed face file. It is convenient to share the same face data in multiple devices.

Face Management			
Search		Search Rese	
	Index	Name	
	1	Akuvox1	0
	2	EVE	
	3	Mike	
	4		
	5		
	6		
	7		
	8		
	9		
	10		
	Page 1 V	Delete	Delete A

Figure 3.8.4.2-2 Face Management

		Face Import/Expo	ort	
Face Data	Choose File	No file chosen	Import	Export

Figure 3.8.4.2-3 Face import/export

3.8.5. Unlock via HTTP Command

Login to the website and go to the path **Intercom - Relay - Open Relay via HTTP** to configure. Users can use a URL to remotely unlock the door. It is more convenient for users to open the door if users are not beside the devices.

Switch: Enable this function. Disable by default.

Username & Password: Users can setup the username and password for HTTP unlock.

URL format:

CYGNUS 🐎

http://IP_address/fcgi/do?action=OpenDoor&UserName=&Pas sword=&DoorNum=1

Open F	Relay via HTTP
Enable	ON V
JserName	admin
Password	

Figure 3.8.5 Open relay via HTTP



3.8.6. Unlock via Exit Button

VTX series supports 3 input triggers Input A/B/C (DOORA/B/C). Login to the website and go to the path **Intercom - Input** to configure.

Input Service: To enable or disable input trigger service.

Trigger Option: To choose open circuit trigger or closed circuit trigger. "Low" means that connection between door terminal and GND is closed, while "High" means the connection is opened.Door Status: To show the status of input signal.

		Input A
Input Service	Enable	•
Trigger Option	Low	•
Action Delay	0	(0~300 <mark>Sec</mark>)
Open Relay	RelayA	•
Door Status	DoorA: High	

Figure 3.8.6 Input

3.9. Reboot

In the phone interface, go to Reboot to click the Reboot, or go to the path Upgrade - Basic on the web GUI, click Submit, the device will restart.



Figure 3.9-1 Reboot

Reboot

Submit

Figure 3.9-2 Reboot

3.10. Reset

In the phone interface, go to **Restore.** Click **Restore**, if users sure

to restore to factory settings, please choose 🥙 in the prompt window.

Users can also login to the website and go to the path **Upgrade** - **Basic**, directly click **Submit** to reset VTX series. Use this function with caution. All configuration will be removed.



Figure 3.10-1 Restore

Reset To Factory Setting Submit

Figure 3.10-2 Reset

4. Advanced Features

4.1. Phone Configuration

4.1.1. IR LED

CYGNUS

The setting is for night vision, when the surrounding of VTX series is very dark, infrared LED will turn on and VTX series will turn to night mode to let the users see video clearly from the VTXS/F. In the phone interface, go to **LED** or go to the path **Intercom** -**Advanced** - **LED** on web GUI, to configure the IR LED function. **Led Type:** It can supports three modes - OFF, ON, AUTO. If setup the LED type as auto, click **Threshold button** to sense the intensity of the current environment.

Threshold: Click the **Threshold key**, it will automatic show the current intensity or user can setup the value manually. Once the environment intensity is darker than the predefined threshold value, LED will be up.

ED
Always OFF 200 - 500 (0~1000)



Min/Max photoresistor: Photoresistor value relates to light intensity and larger value mean that light intensity is smaller. When photoresistor value is greater than max value, LED will turn on. In contrast, when photoresistor value is less than min value, infrared LED will turn off and the device turns to normal mode.

4.1.2. LED of Display

Login to the website and go to the path Intercom - LED Setting -

LED Control to configure.

Card LED Enable: To control the LED of the card reader area. **Start Time (H):** Setup the LED light up time. According to the system time. For example 18-23 means the LED will continuously light up from 6:00pm to 11:00pm.

4.1.3. RFID Card Code Display Related

Login to the website and go to the path Intercom - Advanced -





RFI	D	
RFID Display Mode	8HN	•
IDCARD Display Mode	8HN	•
WIEGAND Display Mode	8HN	•

Figure 4.1.3 RFID

RFID to configure.

Display Mode: To be compatible different card number formats in different systems. The default 8HN means hexadecimal.

4.2. Intercom

4.2.1. Call Time Related

RTP Timeout: Login to the website and go to the path **Intercom** - **Basic** - **Door Setting General** to configure. This feature is specially designed for R47P. When R47P auto answer in mute status, if over the configured time VTX series did not receive the RTP message, VTX series will hang up automatically.

Max Call Time: Login to the website and go to the path Intercom -Basic - Max Call Time to configure the max call time.

Login to the website and go to the path Intercom - Basic - Max

Figure	e 4 2 1 -1 RTP	timeout	
ngur.	5 4 .2.1 -1 1111	lincout	
	Max Call 1	Гime	



Dial Time to configure the max dail time.

Dial In Time: To configure the max incoming dial time, available

when auto answer is disabled.

CYGNUS

Dial Out Time: To configure the max no answer call time.

4.2.2. Return Code When Refused

Login to the website and go to **Phone - Call Feature - Others** to configure.

Return Code When Refuse: Allows users to assign specific code as return code to SIP server when an incoming call is rejected.

4.2.3. SIP Call Related

Login to the website and go to the path **Account - Advanced - Call** to configure the SIP call related functions. **Max Local SIP Port:** To configure maximum local SIP port for designated SIP account.

Max I	Dial Time	
Dial In Time	60	(30~120Sec)
Dial Out Time	60	(30~120Sec)

Figure 4.2.1 -3 Max dial time

	Others	
Return Code When Refuse	486(Busy Here)	•

Figure 4.2.2 Return code when refused

Min Local SIP Port: To configure minimum local SIP port for

designated SIP account.

Caller ID Header: To choose caller ID header format automatically.

Anonymous Call: If enabled, VTX series will block its information when calling out.

Anonymous Call Rejection: If enabled, calls who block their information will be screened out.

Missed Call Log: If enabled, any missed call will be recorded into call log.

Prevent SIP Hacking: If enabled, it will prevent sip message from hacking

4.2.4. Call Waiting

Login to the website and go to the path Phone - Call Feature - Call

Waiting to configure.

Call Waiting Enable: If enabled, it allows IP phones to receive a

	Call		
Max Local SIP Port	5062		(1024~65535)
Min Local SIP Port	5062		(1024~65535)
Caller ID Header	FROM		
Auto Answer	Enabled	•	
Provisional Response ACK	Disabled	•]
Register with user=phone	Disabled]
Invite with user=phone	Disabled	۲]
Anonymous Call	Disabled	Ŧ]
Anonymous Call Rejection	Disabled	Ţ]
Missed Call Log	Enabled	•]
Prevent SIP Hacking	Disabled	۲]

Figure 4.2.3 SIP call related

new incoming call when there is already an active call.

Call Waiting Tone: If enabled, it allows IP phones to play the call waiting tone to the waiting callee.

On Code: The code used to enable call waiting on server's side, if configured, IP phone will send a SIP message to server to turn on call waiting on server side if user setup calls waiting is disabled. **Off Code:** The code used to disable call waiting on server's side, if configured, IP phone will send a SIP message to disable call waiting on server side if user setup call waiting is enabled.

4.2.5. Intercom

Intercom allows users to establish a call directly with the callee. Login to the website and go to the path **Phone - Call Feature -**

Intercom to configure.

Active: To enable or disable Intercom feature.

Intercom Mute: If enabled, once the call established, the callee will be muted.



Figure 4.2.4 Call waiting



Figure 4.2.5 Intercom

Video Codec

VTX series supports H264 standard, which provides better video quality at substantially lower bit rates than previous standards. **Codec Resolution:** VTX series supports four resolutions: QCIF, CIF, VGA, 4CIF and 720P.

Codec Bitrate: To configure bit rates of video stream.

Codec Payload: To configure RTP audio video profile

4.2.7. DTMF

Login to the website and go to the path Account - Advanced -

DTMF to configure RTP audio video profile for DTMF and its payload type.

Type: Support Inband, Info, RFC2833 or their combination.

How To Notify DTMF: Only available when DTMF type is Info.

DTMF Payload: To configure payload type for DTMF.

	Video Codec
Codec Name	H264
Codec Resolution	4CIF T
Codec Bitrate	320 🔻
Codec Payload	104 🔻

Figure 4.2.6-3 Video codec

DTMF		
Туре	RFC2833	
How To Notify DTMF	Disabled	v
DTMF Payload	101	(96~127)

Figure 4.2.7 DTMF

Video Codec

VTX series supports H264 standard, which provides better video quality at substantially lower bit rates than previous standards. **Codec Resolution:** VTX series supports four resolutions: QCIF, CIF, VGA, 4CIF and 720P.

Codec Bitrate: To configure bit rates of video stream.

Codec Payload: To configure RTP audio video profile

4.2.7. DTMF

Login to the website and go to the path Account - Advanced -

DTMF to configure RTP audio video profile for DTMF and its payload type.

Type: Support Inband, Info, RFC2833 or their combination.

How To Notify DTMF: Only available when DTMF type is Info.

DTMF Payload: To configure payload type for DTMF.

	Video Codec
Codec Name	H264
Codec Resolution	4CIF T
Codec Bitrate	320 🔻
Codec Payload	104 🔻

Figure 4.2.6-3 Video codec

	DTMF	
Туре	RFC2833	T
How To Notify DTMF	Disabled	v
DTMF Payload	101	(96~127)

Figure 4.2.7 DTMF

(90~7200s)

۳

•

4.2.8. Session Timer

Go to the path **Account** - **Advanced** - **Session Timer** on the web GUI to configure. If enabled, the on going call will be disconnected automatically once the session expired unless it's been refreshed by UAC or UAS.

4.2.9. NAT

CYGNUS

Login to the website and go to the path Account - Advanced -

NAT to configure.

UDP Keep Alive Messages: The phone will send UDP keep-alive message periodically to router to keep NAT port alive.

UDP Alive Msg Interval: Keep alive message interval.

Rport: It will add remote port into outgoing SIP message for designated account.

	NAT	
UDP Keep Alive Messages	Enabled	T
UDP Alive Msg Interval	30	(5~60s)

Session Timer

Figure 4.2.8 Session timer

Disabled

1800

UAC

Figure 4.2.9 NAT

Disabled



Active Session Expire

RPort

Session Refresher

4.2.10. User Agent

CYGNUS

Login to the website and go to the path **Account - Advanced -User Agent** to configure.

User Agent: One can customize users agent field in the SIP message; if user agent is set to specific value, users can see the information from PCAP. If user agent is not set by default, users can see the company name, model number and firmware version from PCAP.

4.3. Access control

4.3.1. Webrelay

VTX series supports extra web relay. This function is more safety to use DTMF code to remote unlock. Login to the website and go to the path **Phone - Web Relay** to configure.

Web Relay

	User Agent	
User Agent		

Figure 4.2.10 User Agent

Type: Connect web relay and choose the type.

IP Address: Enter web relay IP address.

User Name: It is an authentication for connecting web relay.password: It is an authentication for connecting web relay.Note: Users can modify username and password in web relay

website.

Web Relay Action Setting

Web Relay Action: Web relay action is used to trigger the web relay. The action URL is provided by web relay vendor

Web Relay Key: If the DTMF keys same as the local relay, the web relay will be open with local relay. But if there are different, the web relay is invalid.

Web Relay Extension: The webrelay can only receive the DTMF signal from the corresponding extension number.

Web Relay		
Туре	Default	•
IP Address		
UserName		
Password		

Figure 4.3.1-1 Web relay

Web Relay Action Setting			
Action ID	Web Relay Action	Web Relay Key	Web Relay Extension
Action ID 01		ĺ	
Action ID 02			
Action ID 03			
Action ID 04			
Action ID 05			

Figure 4.3.1-2 Web relay action setting

4.3.2. Wiegand

Login to the website and go to the path **Intercom - Advanced -Wiegand** to configure.

Wiegand Type: Support Wiegand 26,34,58. The different number means different bits.

Wiegand Mode: Input or output. Typically, when you select input, we generally connect the wiegand input device, such as the wiegand card reader. Or VTX series can be used as output, It is generally used to connect the third-party Access Control, then VTX series change the card information as wiegand signal, then transfer to the access control module.

Wiegand Input/Output Order: To make the data from wiegand devices to be normal order or reversed order.

Wiegand Output CRC: To be compatible with the other three party wiegand access control which do not use the standard wiegand order, CRC can correct the order format.

Wi	egand
Wiegand Type	Wiegand-26
Wiegand Mode	Input 🔻
Wiegand Input Order	Normal
Wiegand Output Order	Normal
Wiegand Output CRC	ON T

Figure 4.3.2 Wiegand

4.4. Security

4.4.1. Antialarm of Door Phone

4.4.1.1. Antialarm in device

In the phone interface, go to **AntiAlarm** to configure it.

This function is used to trigger the alarm by perceiving the change of gravity. After the door phone has been installed, administrator can enable Antialarm function. if the device is moved illegally, the gravity of VTX series are different from the original status, then the device will ring alarm bell and send out the call to the predefined location. The detailed gravity sensor value can be adjusted in website.

Tamper Proof Switch: Switch this feature.

Tamper Proof Switch: The smaller the value, the more sensitive the gravity sensor is.

Θ	03:00 AntiAlarm
Tamper Proof Switch:	
Tamper Proof Switch:	32
(c	Save

Figure 4.4.1.1 Antialarm

4.4.1.2. Antialarm in website

Login to the website and go to the path **Intercom - Advanced -Tamper Alarm** to configure.

VTX series integrates internal gravity sensor for the own security, and after enabling tamper alarm, if the gravity of VTX series changes dramatically, the phone will alarm. Gravity sensor threshold stands for sensitivity of sensor.

4.4.2. Motion

CYGNUS

4.4.2.1. Motion in device

In the phone interface, go to **Motion** to configure. By enabling the motion detection function, the door phone will detect and record any change in the surrounding, such as suspicious people loitering around, and send notification message to a monitor unit.

Tamper	Alarm	
Tamper Alarm	OFF	¥
Gravity Sensor Threshold	32	(0~127)

Figure 4.4.1.2 Tamper alarm



Timing setting

If users only enable time mode and setup the interval. VTX series will take the picture in every interval time;

Only enable detection mode, VTX series will capture if there is any change of surrounding in the detection time;

Enable timing mode and detection mode in the same time, if there is no any change of surrounding, VTX series will capture in the interval time. Otherwise, the device will take the picture in detection mode.

4.4.2.2. Motion in website

Login to the website and go to the path Intercom - Motion -Motion Detection Options to configure. Motion Detection: To enable or disable motion detection. Timing: If users only enable time mode and setup the interval . VTX series will take the picture in every interval time. Notification: It supports two types FTP and EMAIL.

Motio	n Detection Options		
Enable	OFF	•]
Timing	OFF	•	
Notification	FTP		
Timing Interval	10		(0~65535 Seconds)
Detection Delay	60		
Capture Delay	10		
Detection Accuracy	20		

Figure 4.4.2.2 Motion detection options

Timing Interval: VTX series will take the picture in the interval time.

Detection Delay: Setup the time interval for detection.

Capture Delay: Setup the capture delay time.

Detection Accuracy: The smaller value, the capture picture is more accurate.

After you setup motion, to configure the target address where to receive the pictures.

4.4.3. Action

Login to the website and go to the path **Intercom - Action** to configure the action related features.

4.4.3.1. Email Notification

The capture will be send to the predefined email address or FTP path. It is useful for users to check the capture picture for security.

Sender's email address: To configure email address of sender.

Receiver's email address: To configure email address of receiver.

SMTP server address: To configure SMTP server address of sender.

SMTP user name: To configure user name of SMTP service (usually it is same with sender's email address).

SMTP password: To configure password of SMTP service (usually it is same with the password of sender's email).Email subject: To configure subject of email.

Email content: To configure content of email.

Email Test: To test whether email notification is available.

4.4.3.2. FTP Notification

FTP Server: To configure URL of FTP server.FTP User Name: To configure user name of FTP server.FTP Password: To configure password of FTP server.

	Email Notification	
Sender's email address	info@cygnus.la	
Email SendName	Cygnus	
Receiver's email address	info@cygnus.la	
Email RecvName	Cygnus	
SMTP server address	smtp.email.qq.com	Port 465
SMTP user name	Cygnus	
SMTP password		
Email subject	test	
Email content	test1	

Figure 4.4.3.1 Email notification

FTP Notification	
FTP Server	192.168.16.137
FTP User Name	admin
FTP Password	
FTP Path	picture

Figure 4.4.3.2 FTP notification

FTP Path: Enter the folder name you created in FTP server.

4.4.3.3. Input Interface Triggered Action

Go to the path Intercom - Input on the website to configure.

Action Delay: To configure after how long to execute to send out notifications and trigger relay.

Open Relay: To configure which relay to trigger.

4.5. Upgrade

CYGNUS

4.5.1. Web Update

Login to the website and go to the path **Upgrade - Basic**, users can upgrade firmware.

Upgrade: Choose .zip/.rom firmware from your PC, then click Submit to start update.

Firmware Version	29.0.1.224
Hardware Version	29.3.0
Upgrade	Choose File No file choser
	Submit Cancel

Figure 4.5.1 Web update

Action Delay	0	(0~300 Sec)	
Open Relay	RelayA	▼1	

Figure 4 4 3 3 Input interface triggered action

4.5.2. Autop Upgrade

Login to the website and go to the path **Upgrade** - **Advanced** to configure.

Manual Autop

Autop is a centralized and unified upgrade of IP telephone. It is a simple and time-saving configuration for IP phone. It is mainly used by the device to download corresponding configuration document from the server using TFTP / FTP / HTTP / HTTPS network protocol. To achieve the purpose of updating the device configuration, making the user to change the phone configuration more easily. This is a typical C/S architecture upgrade mode, mainly by the terminal device or PBX server to initiate an upgrade request.

URL: Auto provisioning server address.

User name: Configure if server needs an username to access, otherwise left blank.

URL	tftp: //192.168.16.137
User Name	
Password	•••••
Common AES Key	•••••
AES Key(MAC)	


Password: Configure if server needs a password to access, otherwise left blank.

Common AES Key: Used for IP phone to decipher common Auto Provisioning configuration file.

AES Key (MAC): Used for IP phone to decipher MAC-oriented auto provisioning configuration file (for example, file name could be 0c1105888888.cfg if IP phone's MAC address is 0c1105888888). **Note:** AES is one of many encryption, it should be configured only when configure file is ciphered with AES, otherwise left blank.

Automatic Autop

To display and configure Auto Provisioning mode settings. This Auto Provisioning mode is actually self-explanatory. For example, mode "Power on" means IP phone will go to do Provisioning every time it powers on.

DHCP Option

To display and configure DHCP setting for AutoP. Option 66/43 is enable by default. It can support Https, Http, Ftp, Tftp server.









Customer Option: Enter the server URL. Click Submit to save.

4.5.3. Backup Config File

CYGNUS

Go to the path **Upgrade - Advanced - Others** to backup the config file.

Others:To export current config file or import new config file. **Note:** The exported config is encrypted.

Users can also go to the path **Phone - Import/Export -Import/Export Config&Contact** to export or import the config. Click **Export** to export the config file. And users can modify configuration item in config file then import it from local side.

Config File(.tgz/.conf/.cfg)		Choose File No file chosen
		Export (Encrypted)
		Import Cancel
	Figuro	1531 Config
	Figure	4.5.3-1 Comig
fig:	Choose File No file choose	sen Import Export

4.6. Log

4.6.1. Call Log

Login to the website and go to the path **Phonebook** - **Call Log**, users can see a list of call which have dialed, received or missed. And user can delete calls from list.

4.6.2. Door Log

Login to the website and go to the path **Phone - Door Log**, users can see a list of door log which records card information and date.

4.6.3. System Log

Go to the path Upgrade - Advanced - System Log on web GUI.
To display system log level and export system log file.
System Log Level: From level 0 to 7. The higher level means the more specific system log is saved to a temporary file. By default,

Call History			All Active Enabled Export				
Index	Туре	Date	Time	Local Identity	Name	Number	10
1	Dialed	2018-09-30	06:04:18	192.168.16.2 20@192.168.1 6.220	192.168.16.187	<u>192.168.16.1</u> 87@192.168.1 6.187	8
2	Received	2018-09-30	06:03:21	192.168.16.2 20@192.168.1 6.220	192.16 <mark>8.</mark> 16.187	<u>192.168.16.1</u> <u>87@192.168.1</u> 6.187	O
3	Received	2018-09-30	03:51:27	192.168.16.2 20@192.168.1 6.220	192.168.16.134	<u>192.168.16.1</u> <u>34@192.168.1</u> 6.134	۵
4	Received	2018-09-30	03:41:36	192.168.16.2 20@192.168.1 6.220	192.168.16.134	<u>192.168.16.1</u> <u>34@192.168.1</u> <u>6.134</u>	D

Figure 4.6.1 Call log

DoorLog Active Enabled					ort		
Index	Name	Code	Туре	Date	Time	Status	
1	Unknown	FF96A228	Card	2018-09-29	06:43:48	Failed	
2	Unknown	FF96A228	Card	2018-09-29	06:41:15	Failed	
3							
4							
5							
6							

Figure 4.6.2 Door log

System Log		
LogLevel	3 🔻	
Export Log	Export	

Figure 4.6.3 System log



it's level 3.

Export Log: Click to export temporary system log file to local PC.

4.6.4. PCAP

Go to the path Upgrade - Advanced - PCAP on web GUI. To start,

stop packets capturing or to export captured Packet file.

Start: To start capturing all the packets file sent or received from IP phone.

Stop: To stop capturing packets.



Figure 4.6.4 PCAP

Abbreviations

ACS: Auto Configuration Server	DNS-SRV: Service record in the Domain Name System
Auto: Automatically	FTP: File Transfer Protocol
AEC: Configurable Acoustic and Line Echo Cancelers	GND: Ground
ACD: Automatic Call Distribution	HTTP: Hypertext Transfer Protocol
Autop: Automatical Provisioning	HTTPS: Hypertext Transfer Protocol Secure
AES: Advanced Encryption Standard	IP: Internet Protocol
BLF: Busy Lamp Field	ID: Identification
COM: Common	IR: Infrared
CPE: Customer Premise Equipment	LCD: Liquid Crystal Display
CWMP: CPE WAN Management Protocol	LED: Light Emitting Diode
DTMF: Dual Tone Multi-Frequency	MAX: Maximum
DHCP: Dynamic Host Configuration Protocol	POE: Power Over Ethernet
DNS: Domain Name System	PCMA: Pulse Code Modulation A-Law
DND: Do Not Disturb	PCMU: Pulse Code Modulation µ-Law

PCAP: Packet Capture	SIP: Session Initiation Protocol
PNP: Plug and Play	SNMP: Simple Network Management Protocol
RFID: Radio Frequency Identification	STUN: Session Traversal Utilities for NAT
RTP: Real-time Transport Protocol	SNMP: Simple Mail Transfer Protocol
RTSP: Real Time Streaming Protocol	SDMC: SIP Devices Management Center
MPEG: Moving Picture Experts Group	TR069: Technical Report069
MWI: Message Waiting Indicator	TCP: Transmission Control Protocol
NO: Normal Opened	TLS: Transport Layer Security
NC: Normal Connected	TFTP: Trivial File Transfer Protocol
NTP: Network Time Protocol	UDP: User Datagram Protocol
NAT: Network Address Translation	URL: Uniform Resource Locator
NVR: Network Video Recorder	VLAN: Virtual Local Area Network
ONVIF: Open Network Video Interface Forum	WG: Wiegand



Contact us

For more information about the product, please visit us at **www.cygnus.la** or feel free to contact us by

Sales email: info@cygnus.la

Technical support email: soporte@cygnus.la

Telephone: Tel. (+5411) 5277-4441

We highly appreciate your feedback about our products.



